


DTSW+2SW 1810



DTSW+2SW 1811


DTSW+2SW 1810 DTSW+2SW 1811

D	Montageanleitung
GB	Installation instructions
F	Instructions de montage
I	Istruzioni di montaggio
E	Instrucciones de montaje
NL	Montagehandleiding
GR	Οδηγία συναρμολόγησης
RUS	Инструкция по монтажу
DK	Montagevejledning
CZ	Návod k instalaci
PL	Instrukcja montażu
S	Monteringsanvisning
P	Instrução de montagem
H	Szerelési utasítás







1a




A	B	C
800	774-789	760-780
900	874-889	860-880
1000	974-989	960-980
1200	-	1160-1180
SOMI	A-20	A-40




1b




2




3




4




5




6a




6b







7a








7b





8





11



12

